

**APPLICATION OF 100%ACRYLIC, HEAT INSULATION, ANTI CARBONATION & WATERPROOFING PAINT FOR EXTERNAL WALL SURFACES**

Clean the surface of all loose particles, dirt & flaking paint & rub down to original hard surface.

Examine for cracks if any & seal the same with **POLYFILL-AR**. Severe cracks to be sealed with **POLYALK EP** & Cement in the ratio 2:5:15 with application of Bonding coat

Apply first coat of **SUNEXT-8** by brush, roller or spray. Mix one litre of SUNEXT-8 in 500 ml.of potable water in a clean container and apply on the clean surface.

After 4-6 hours interval apply two more coat of **SUNEXT-8**