SPECIFICATION FOR BONDING OF PLASTER TO RCC SURFACE

Clean the RCC surface of all the loose particles, oil, grease etc. Wet the surface.

↓

Apply ready to use single pack Bonding Agent ***HACK –AID PLAST*** on the receiving surface by spray. Avoid using brushes as they tend to get clogged and affect performance.

↓

Wait for ***HACK –AID PLAST*** to become tacky which generally occurs within approximately 10 mins of its application. However tacky period may vary depending on external atmospheric conditions, saturation degree of substrate etc. User should please check for the same prior to application.

↓

As soon as the Bonding coat becomes wet and tacky provide a cement chat coat of cement and sand.

↓

Plaster the surface as usual adding ***SUNPLEX*** (330 gms) pouch per 50 kg bag of cement. Cure as usual.